



POLL PAD KIOSK QUICK START GUIDE

1 OPEN CASE

Locate and open transport case.

2 REMOVE UNIT

Remove Poll Pad Kiosk from transport case.

3 CONNECT IPAD CHARGING CORD

Connect green charging cord into lightning port.

4 ID TRAY

Locate and attach ID tray using the mounting clip on back of Poll Pad Kiosk.

5 CONNECT PRINTER TO POWER ADAPTER

Connect the printer power cord to the power adapter.

NOTE: Ensure secure connection.

6 PLUG PRINTER INTO OUTLET

Plug printer cord into AC power source. **NOTE:** Make sure your check-in table is close to a wall outlet or an extension cord or power strip is available.

7 TURN PRINTER ON

Press power button located on the front of printer.

Printer is powered on when blue light illuminates.

